



1

2

3

4

6

8

10

11

7

9

12

20

12

13

14

15

16

17

18

19

21

22

23

24

25

Rubber Spring

Left

Right

Cable Clip

AB CD 123
2-3 mm = A x2
4-5 mm = B x2

Číslo	Obj.číslo	Názov náhradného dielu	Cena s DPH
1	1500052680	Bike Frame	49,99 €
2	1500050895	Mounting Bag RMS	9,99 €
3	1500054223	Bike Arm 372mm Black	44,99 €
4	1500054112	Bike Arm 122mm-30 torque knob	34,99 €
5	1500052738	AcuTight Knob	34,99 €
6	1500054185	Rubber Spring Kit	9,99 €
7	1500052692	MtgBag console cover 1+2	9,99 €
8	1500052681	Mtg Bag Wheel strap 917/918	9,99 €
9	1500052682	Mtg Bag Pumpbuckle	19,99 €
10	1500052691	MtgBag cable connector 917	39,99 €
11	1500052603	Housing Foot VC 2.0	9,99 €
12	1500052690	MtgBag Endcap cover	9,99 €
13	1500052906	Endcap Wheeltray L	9,99 €
14	1500052908	Lampholder 13p L	14,99 €
15	1500052733	Lamp Left	49,99 €
16	1500054656	MtgBag Lampcover L	
17	1500052540	Cable Clip	1,99 €
18	1500052910	Number Plate Holder	19,99 €
19	1500052598	Replacement Clips	4,99 €
20	1500052907	Endcap Wheeltray R	9,99 €
21	1500052909	Lampholder 13p R	14,99 €
22	1500052734	Lamp Right	49,99 €