



Číslo	Obj.číslo	Názov náhradného dielu	Cena s DPH
1	1500054681	Bike frame	34,99 €
2	1500054680	Bike frame kit	24,99 €
3	1500054167	Bike Arm 482 mm 30 torque knob	59,99 €
4	1500054166	Bike Arm 302 mm 30 torque knob	44,99 €
5	1500054112	Bike Arm 122mm-30 torque knob	34,99 €
6	1500052738	AcuTight Knob	34,99 €
7	1500054185	Rubber Spring Kit	9,99 €
8	1500052681	Mtg Bag Wheel strap 917/918	9,99 €
9	1500052682	Mtg Bag Pumpbuckle	19,99 €
10	1500052691	MtgBag cable connector 917	39,99 €
11	1500052914	Wheeltray Endcap	4,99 €
12	1500054313	Spring Tilt	4,99 €
13	1500052915	Endcap Cover	4,99 €
14	1500052912	Endcap Wheeltray L	14,99 €
15	1500052908	Lampholder 13p L	14,99 €
16	1500052733	Lamp Left	49,99 €
17	1500054656	MtgBag Lampcover L	
18	1500052540	Cable Clip	1,99 €
19	1500052910	Number Plate Holder	19,99 €
20	1500052598	Replacement Clips	4,99 €
21	1500052913	Endcap Wheeltray R	14,99 €